

create walls with style...it's easy™

easyascot®



Colonial

or

Tropical

or

Modern

or

Classic

Transform a room from ordinary
to extraordinary

It's easy with easyascot®

Be Inspired and **D.I.Y.**

 **EASYCRAFT®**
Innovative Wall Linings

How do I do it?

easyascot® can be installed instead of run-of-the-mill linings such as fibre cement or plasterboard. If your walls are already lined then easyascot® goes straight over the top.....**it's easy**

What will I need?

- | | |
|--|---|
| <input type="checkbox"/> Tape Measure | <input type="checkbox"/> Saw (Circular or Hand) |
| <input type="checkbox"/> Pencil (not a pen) | <input type="checkbox"/> Hammer |
| <input type="checkbox"/> Spirit Level | <input type="checkbox"/> Nails |
| <input type="checkbox"/> String Line | <input type="checkbox"/> Dust Mask |
| <input type="checkbox"/> Construction Adhesive | <input type="checkbox"/> Safety Goggles |

_____ **x easyascot® panels** (Measure the length of wall/s you are covering and divide by 600mm. Always round up e.g. 8.4 will become 9 panels).

_____ **x easydado® rails** (3.6m each)

Let's Start!

1. Remove existing skirting boards.
2. Start in the middle of each wall and draw a plumb (vertical) line.
 - A. For an even number of panels, place the first panel adjacent to the line.
 - B. For an odd number of panels, place the first panel squarely over the line.
3. Allow a 10mm gap from the floor. (use a spacer to make this easy)
4. Apply construction adhesive to the wall, plumb with a spirit level and nail the panel into the studs.
5. Butt up the next panel and repeat.
6. Continue until a full panel won't fit. At this point, reverse a panel, cut to size and place in gap.
7. Place easydado® rail along the top edge.
8. Replace skirting boards and paint to suit.
9. Sit back and accept the praise.

NB. *Please see our website for full installation instructions. *

www.easycraft.com.au



Available from your local easycraft® stockist

